



Installation Instructions

5922, 23

1.0 General

- 1.1 These instructions document the installation of the 5922, 23 Enclosure

2.0 Customer Service

- 2.1 Installation questions concerning this unit can be handled by calling the manufacturer directly. Contact a customer service representative at 801-936-8082.

2.2 Limited New Product Warranty

- 2.2.1 Surround products produced by Companion Systems Inc. (CSI) are covered by warranty.

- 2.2.2 Voiding of Warranties: These installation instructions are an integral part of the product warranties given by Companion Systems to the customer. Proper operation and maximum performance of the product depend upon proper installation.

In the event that the product is installed by the customer, or by anyone performing the installation at the customer request, in any manner other than in strict compliance with these instructions and specifications, all warranties express or implied, are void. All repairs and other modifications to the product necessary to bring the installation in compliance with these instructions will be at the customers' sole expense.

Warranty-related claims or questions may be made by calling CSI Customer Service at 801-936-8082.

3.0 Maintenance

3.1 Monthly

- 3.1.1 To protect the finish of the Enclosure, wash with soap and water to remove dust, dirt and other debris. Wash and dry the exterior of the Enclosure in a straight motion along the length of the Enclosure. Use a natural chamois or terry cloth towel for drying.

- 3.1.2 Remove all accumulated trash and debris from around the unit.

3.2 Biannually

- 3.2.1 Wash and wax the exterior of the Kiosk. Use any name brand liquid or paste automotive wax. They are easy to use and provide excellent protection. Apply the wax in circular motion and finish by wiping in a straight motion along the length of the Kiosk. This results in a uniform drying pattern. After it is applied to one section, move to the next section and let the first area dry (per the wax manufacturer recommendations). Then go back and polish the first area. Continue this process until the Kiosk is completely waxed and polished.

4.0 Transportation and Handling

- 4.1 While transporting, uncrating, and handling, do not set the sign against any obstruction without the appropriate padding
- 4.2 The boxes should be examined when received for any shipping damage.
- 4.3 Remove the packing material on site unless damage has occurred.
- 4.4 When removing the sign from the packing material make sure not to damage the product while cutting off the plastic wrap.

5.0 Instructions

5.1 Hardware Included

Suction Cup
Self Tapping Screws

5.2 Tools and Supplies

Electric drill and bits (Optional)
Electrical hand tools (Optional)
Rags and spray cleaner

6.0 Installation

6.1 General Information

- 6.1.1 Clean the area where the Enclosure will sit with a household cleaner and let the area dry.
- 6.1.2 Position the Enclosure on the ATM. Mark the location with a pencil for future reference.
- 6.1.3 Remove then Enclosure From the ATM.
- 6.1.4 Remove the paper protector from the double stick tape located on the bottom of the Enclosure.
- 6.1.5 Place the Enclosure on the top of the ATM in the desired position. Press down all along the taped areas to seat the tape.
- 6.1.6 **Optional** - Find the self-drilling screws in a packet taped to the unit. Open the ATM and inspect the location where the screws will go through. Make sure that there are no wires or other items that can be damaged by the screws. Drive the screws through the bottom of the unit and into the ATM metal cabinet.

6.2 Finalization

6.2.1 Clean up all packing and construction materials.

6.2.2 Clean the surround per the maintenance instruction of this document.

7.0 Sign Removal

7.1 Place the suction cup provided with the Enclosure, at the top center of the sign.

7.2 Gently pull the sign until it disengages from the end caps and you are able to grasp the sign.

8.0 Revision History

Revision	Date	Description
A	03/25/2010	Initial Release